



Switch position

S1	1	2	3	4	5	6	7	8	9	10
1-2										
3-4										
5-6										
7-8										
9-10										
11-12										
13-14										
15-16										
17-18										
19-20										
21-22										
23-24										

Switch position

S2	A	B	C
1-2			
3-4			
5-6			
7-8			
9-10			
11-12			
13-14			
15-16			
17-18			

Connections between X11 of feeder socket and X10 of source:

- | | |
|-----|-----|
| X11 | X10 |
| A | I |
| B | K |
| C | C |
| D | D |
| E | H |
| F | G |
| G | F |
| H | E |



POWERTEC 365S (50242)